



**11AA16**  
Box-power for single ceiling installation.



**11AA16RDD**  
Box-power for single ceiling installation, DALI version.



**11AA16R**  
Box-power for recessed installation.



**11AA16RRDD**  
Box-power for recessed installation, DALI version.



**11AA16IL**  
Box-power for start continuous rows.



**11AA16ILRDD**  
Box-power for start continuous rows, DALI version.



**11AA16CL**  
Box-power for centre continuous rows.



**11AA16CLRDD**  
Box-power for centre continuous rows, DALI version.




**11AA16FL**  
Box-power for end continuous rows.




**11AA16FLRDD**  
Box-power for end continuous rows, DALI version.

CEILING



SUSPENDED



ENDLESS CONFIGURATION POSSIBILITIES

